



### IMPORTANT

- It is the installer's duty to test the strength of wall, floor or ceiling and to decide on the most appropriate anchoring hardware. Anchoring hardware is not supplied by us.
- A careful evaluation of the ceiling where the rods are to be installed must be carried out prior to installing the rods.
- It is necessary to evaluate the weight of your displays, so that the rods are not overloaded.
- Do not use power tools to tighten rod systems or set screws.

### INSTALLATION STEPS

1. Take accurate measurements of the shelves, panels or other displays to be suspended. Define the top and bottom anchoring points by using a plumb line.
2. Affix the R1 to the ceiling or wall. (Top anchoring point)
3. Screw the R3 onto R1.
4. Affix the other R8 to the floor. (Bottom anchoring point)
5. Screw the first rod into the R3. If there are more than 1 rod, screw each additional rod into each other leaving the last one out.  
\*If installing only one rod, please go directly to step 6.
6. Take the last rod and cut it to the length corresponding to the distance between the floor and the the hanging rod minus 5/8".  
\*If installing only one rod, cut the rod to the length corresponding to the distance between the R3 and the bottom of the CM51 minus 5/8".
7. Using the Allen key provided, screw the R7 tightly to the bottom edge (cut end) of the last rod (which has not been screwed into the other rods). Then slide on the R6 and the R5 over the male end of the rod.
8. Insert the bottom of the last rod inside the R8 and then screw the top end into the hanging rod. Screw the R5 into the R8 to tension the rod.  
\*If you find the rod is too loose, it may be necessary to raise the R7 slightly and retighten the lower assembly.

*These installation instructions are only to be used as **guidelines**. It is the installer's responsibility to ensure that anchoring hardware and materials used in any installation meet the demands of their intended purpose.*

